
IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

↑ DISCONNECT THE MAIN LINE BEFORE WIRING SECONDARY CONNECTORS.

INSTALLATION ON SURFACE (WALL / FLOOR) WITH 4" JUNCTION BOX - REMOTE DRIVER (REM) (24V)

- A- MARK ANCHORS POSITION ON THE WALL RESPECTING THE HOLE TEMPLATE BELOW WITH PRE-INSTALLED JUNCTION BOX (BY OTHERS). INSTALL (4) ANCHORS (BY OTHERS).
- B- PASS CABLE THROUGH CENTER HOLE OF MOUNTING PLATE, LIQUID-TIGHT CONNECTOR AND CROSSBAR, AS SHOWN BELOW. MAKE ALL NECESSARY ELECTRICAL CONNECTIONS IN JUNCTION BOX.
- C- INSTALL THE CROSSBAR AND THE MOUNTING PLATE ON SURFACE USING INCLUDED SCREWS, AS SHOWN BELOW.
- D- UNFASTEN THE BASE COVER MOUNTING SCREWS AND SLIDE THE BASE COVER OVER THE ARM.
- E- INSTALL THE FIXTURE ON MOUNTING PLATE USING PROVIDED (4) SCREWS.
- F- RE-INSTALL THE BASE COVER AND FASTEN THE (2) SCREWS
- G- ROTATE THE FIXTURE TO THE DESIRED POSITION AND LOCK IN PLACE BY FASTENING THE (2) SET SCREWS.

A + B + C + D + E + F + G



CL - R2 Last update: August 20, 2020

